



QUICK FIST XL clamp – Item #60060

Quick Overview

- Two 14" (356mm) separate straps hold objects up to 15" (381mm) in diameter.
- Holds equipment measuring up to 28" (711mm) in linear distance.
- Each clamp supports a safe working load of 150 lbs (68 kilos) with a break-strength of 300lbs. (176 kilos)
- Two clamps support 300lbs with a break-strength of 600lbs (272 kilos).
- Each half of the clamp mounts with four #10 screws or bolts.
- Mounting area: 2" x 2" (51mm x 51mm)

Installation Instructions

- The two pieces of the clamp must be mounted with each side facing as illustrated and with the arrows on each base facing each other. Use four #10 bolts or screws and appropriate size washers to fasten each base. Do not over tighten.
- If you plan on holding a large cylinder and the base is not supported, it is advisable to use a piece of angle iron, wood block or shelf bracket to support the bottom of the cylinder. This will also make it easier to lock the clamp in place.
- Mount the base so that the strap is parallel to the outside edge of whatever you are holding.
- The "ladder" half of the clamp can be stretched up to about an inch by pulling on the strap (NOT the ladder "steps" or cross pieces) in several places along its length.
- If you are holding a cylinder, tighten by putting the "jaw" half through the tightest "ladder" section and then pull the two halves in opposing directions. If you are tightening a rectangular piece of equipment, you need to push the "ladder" half as far as possible while keeping the "jaw" section flat.